


# EATON SINGLE PHASE MAGNETIC STARTER WIRING DIAGRAM

## PRESSURE SWITCH WIRES:

- 1 WIRE FROM MOTOR TERMINAL ON PRESSURE SWITCH TO DOUBLE SPADE TERMINAL ON MAGNETIC STARTER
- 1 WIRE FROM "LINE" TERMINAL ON PRESSURE SWITCH CONNECTED TO COIL TERMINAL SPADE IN BACK OF MAGNETIC STARTER



**INCOMING 230 VOLT POWER CONNECT TO L1 & L2**

**MOTOR WIRES HOOK TO T1 & T3 TERMINALS**

**MOTOR**